


## Operating Guide

# PSB 9000 3U Slave

## Bidirectional DC Power Supply



Attention! This document is only valid for devices with firmwares "KE: 2.28", "HMI: 2.02" and "DR: 2.0.6" or higher.

Doc ID: PSB9SEN

Revision: 02

Date: 06/2020





## TABLE OF CONTENTS

**1 GENERAL**

1.1	About this document.....	4
1.1.1	Retention and use.....	4
1.1.2	Copyright.....	4
1.1.3	Validity.....	4
1.1.4	Symbols and warnings.....	4
1.2	Warranty.....	4
1.3	Limitation of liability.....	4
1.4	Disposal of equipment.....	5
1.5	Product key.....	5
1.6	Intended usage.....	5
1.7	Safety.....	6
1.7.1	Safety notices.....	6
1.7.2	Responsibility of the user.....	6
1.7.3	Responsibility of the operator.....	7
1.7.4	User requirements.....	7
1.7.5	Alarm signals.....	8
1.8	Technical Data.....	8
1.8.1	Approved operating conditions.....	8
1.8.2	General technical data.....	8
1.8.3	Specific technical data.....	9
1.8.4	Views.....	13
1.8.5	Control elements.....	16
1.9	Construction and function.....	17
1.9.1	General description.....	17
1.9.2	Block diagram.....	17
1.9.3	Scope of delivery.....	18
1.9.4	The control panel (HMI).....	18
1.9.5	USB port type B (rear side).....	19
1.9.6	"Share" connector.....	19
1.9.7	"Sense" connector (remote sensing).....	19
1.9.8	Master-Slave bus.....	19

**2 INSTALLATION & COMMISSIONING**

2.1	Transport and storage.....	20
2.1.1	Transport.....	20
2.1.2	Packaging.....	20
2.1.3	Storage.....	20
2.2	Unpacking and visual check.....	20
2.3	Installation.....	20
2.3.1	Safety procedures before installation and use.....	20
2.3.2	Preparation.....	20
2.3.3	Installing the device.....	22
2.3.4	Connection to AC supply.....	23
2.3.5	Connection to DC loads.....	25
2.3.6	Grounding of the DC terminal.....	26
2.3.7	Connection of remote sense.....	26
2.3.8	Connecting the "Share" bus.....	27
2.3.9	Connecting the USB port.....	27
2.3.10	Initial commission.....	28
2.3.11	Commission after a firmware update or a	

long period of non-use.....	28
-----------------------------	----

**3 OPERATION AND APPLICATION**

3.1	Terms.....	29
3.2	Personal safety.....	29
3.3	Operating modes.....	29
3.3.1	Voltage regulation / Constant voltage.....	29
3.3.2	Current regulation / constant current / current limiting.....	30
3.3.3	Power regulation / constant power / power limiting.....	30
3.3.4	Internal resistance regulation (source mode).....	31
3.3.5	Resistance regulation / constant resistance (sink mode).....	31
3.3.6	Sink-source mode switching.....	32
3.4	Alarm conditions.....	33
3.4.1	Power Fail.....	33
3.4.2	Overtemperature.....	33
3.4.3	Overvoltage protection.....	33
3.4.4	Overcurrent protection.....	33
3.4.5	Overpower protection.....	34
3.4.6	Safety OVP.....	34
3.5	Manual operation.....	35
3.5.1	Powering the device.....	35
3.5.2	Switching the device off.....	35
3.5.3	Switching the DC terminal on or off.....	35
3.6	Remote control.....	36
3.6.1	General.....	36
3.6.2	Remote control via the rear USB.....	36
3.6.3	Remote control via the front USB.....	36
3.6.4	Programming.....	37
3.7	Alarms and monitoring.....	38
3.7.1	Definition of terms.....	38
3.7.2	Device alarm and event handling.....	38

**4 SERVICE AND MAINTENANCE**

4.1	Maintenance / cleaning.....	40
4.2	Fault finding / diagnosis / repair.....	40
4.2.1	Firmware updates.....	40

**5 CONTACT AND SUPPORT**

5.1	General.....	41
5.2	Contact options.....	41

## 1. General

### 1.1 About this document

#### 1.1.1 Retention and use

This document is to be kept in the vicinity of the equipment for future reference and explanation of the operation of the device. This document is to be delivered and kept with the equipment in case of change of location and/or user.

#### 1.1.2 Copyright

Reprinting, copying, also partially, usage for other purposes as foreseen of this manual are forbidden and breach may lead to legal process.




#### 1.1.3 Validity

This manual is valid for the following equipment:

Model	Article number
PSB 9060-360 3U Slave	30090321
PSB 9080-360 3U Slave	30090312
PSB 9200-210 3U Slave	30090313
PSB 9360-120 3U Slave	30090314
PSB 9500-90 3U Slave	30090315
PSB 9750-60 3U Slave	30090316
PSB 91000-40 3U Slave	30090317
PSB 91500-30 3U Slave	30090318

#### 1.1.4 Symbols and warnings

Warning and safety notices as well as general notices in this document are shown in a box with a symbol as follows:

	<b>Symbol for a life threatening danger</b>
	Symbol for general safety notices (instructions and damage protection bans) or important information for operation
	<i>Symbol for general notices</i>

## 1.2 Warranty

EPS Stromversorgung guarantees the functional competence of the applied technology and the stated performance parameters. The warranty period begins with the delivery of free from defects equipment.

Terms of guarantee are included in the general terms and conditions (TOS) of EPS Stromversorgung.

## 1.3 Limitation of liability

All statements and instructions in this manual are based on current norms and regulations, up-to-date technology and our long term knowledge and experience. The manufacturer accepts no liability for losses due to:

- Usage for purposes other than designed
- Use by untrained personnel
- Rebuilding by the customer
- Technical changes
- Use of not authorized spare parts

The actual delivered device(s) may differ from the explanations and diagrams given here due to latest technical changes or due to customized models with the inclusion of additionally ordered options.

## 1.4 Disposal of equipment

A piece of equipment which is intended for disposal must, according to European laws and regulations (ElektroG, WEEE) be returned to the manufacturer for scrapping, unless the person operating the piece of equipment or another, delegated person is conducting the disposal. Our equipment falls under these regulations and is accordingly marked with the following symbol:



## 1.5 Product key

Decoding of the product description on the label, using an example:

**PSB 9 080 - 360 3U Slave**

	Construction:
	<b>Slave</b> = Ancillary unit for master-slave operation
	<b>3U</b> = 3 rack units of height
	Maximum current of the device in Ampere
	Maximum voltage of the device in Volt
	Series: <b>9</b> = Series 9000
	Type identification:
	<b>PSB</b> = Power Supply Bidirectional

## 1.6 Intended usage

The equipment is intended to be used, if a power supply or battery charger, only as a variable voltage and current source, or, if an electronic load, only as a variable current sink.

Typical application for a power supply is DC supply to any relevant user, for a battery charger the charging of various battery types and for electronic loads the replacement of an ohmic resistor by an adjustable DC current sink in order to load relevant voltage and current sources of any type.



- Claims of any sort due to damage caused by non-intended usage will not be accepted.
- All damage caused by non-intended usage is solely the responsibility of the operator.

## 1.7 Safety

### 1.7.1 Safety notices

#### Mortal danger - Hazardous voltage



- All work on connections must be carried out under zero voltage (DC terminal not connected to load) and may only be performed by qualified and informed persons. Improper actions can cause fatal injury as well as serious material damage.
- Never touch cables or connectors directly after unplugging from mains supply as the danger of electric shock remains!
- Never touch the contacts on DC terminal directly after switching off the DC terminal, because there still can dangerous voltage present, sinking more or less slowly depending on the load! There also can be dangerous potential between the negative DC terminal and PE or the positive DC terminal and PE due to charged X capacitors.



- The equipment must only be used as intended
- The equipment is only approved for use within the connection limits stated on the product label.
- Do not insert any object, particularly metallic, through the ventilator slots
- Avoid any use of liquids near the equipment. Protect the device from wet, damp and condensation.
- For power supplies and battery chargers: do not connect loads, particularly ones with low resistance, to devices under power; sparking may occur which can cause burns as well as damage to the equipment and to the load.
- For electronic loads: do not connect power sources to equipment under power, sparking may occur which can cause burns as well as damage to the equipment and to the source.
- ESD regulations must be applied when plugging interface cards or modules into the relative slot
- Interface cards or modules may only be attached or removed after the device is switched off. It isn't necessary to open the device.
- Do not connect external power sources with reversed polarity to DC input or outputs! The equipment will be damaged.
- For power supply devices: avoid where possible connecting external power sources to the DC output, and never those that can generate a higher voltage than the nominal voltage of the device.
- For electronic loads: do not connect a power source to the DC input which can generate a voltage more than 120% of the nominal input voltage of the load. The equipment isn't protected against over voltage and may be irreparably damaged.
- Never insert a network cable which is connected to Ethernet or its components into the master-slave socket on the rear side of the device!
- Always configure the various protecting features against overcurrent, overpower etc. for sensitive loads to what the target application requires!

### 1.7.2 Responsibility of the user

The equipment is in industrial operation. Therefore the operators are governed by the legal safety regulations. Alongside the warning and safety notices in this manual the relevant safety, accident prevention and environmental regulations must also be applied. In particular the users of the equipment:

- must be informed of the relevant job safety requirements
- must work to the defined responsibilities for operation, maintenance and cleaning of the equipment
- before starting work must have read and understood the operating manual
- must use the designated and recommended safety equipment.

Furthermore, anyone working with the equipment is responsible for ensuring that the device is at all times technically fit for use.

## 1.7.3 Responsibility of the operator

Operator is any natural or legal person who uses the equipment or delegates the usage to a third party, and is responsible during its usage for the safety of the user, other personnel or third parties.

The equipment is in industrial operation. Therefore the operators are governed by the legal safety regulations. Alongside the warning and safety notices in this manual the relevant safety, accident prevention and environmental regulations must also be applied. In particular the operator has to

- be acquainted with the relevant job safety requirements
- identify other possible dangers arising from the specific usage conditions at the work station via a risk assessment
- introduce the necessary steps in the operating procedures for the local conditions
- regularly control that the operating procedures are current
- update the operating procedures where necessary to reflect changes in regulation, standards or operating conditions.
- define clearly and unambiguously the responsibilities for operation, maintenance and cleaning of the equipment.
- ensure that all employees who use the equipment have read and understood the manual. Furthermore the users are to be regularly schooled in working with the equipment and the possible dangers.
- provide all personnel who work with the equipment with the designated and recommended safety equipment

Furthermore, the operator is responsible for ensuring that the device is at all times technically fit for use.

## 1.7.4 User requirements

Any activity with equipment of this type may only be performed by persons who are able to work correctly and reliably and satisfy the requirements of the job.

- Persons whose reaction capability is negatively influenced by e.g. drugs, alcohol or medication may not operate the equipment.
- Age or job related regulations valid at the operating site must always be applied.



### **Danger for unqualified users**

**Improper operation can cause person or object damage. Only persons who have the necessary training, knowledge and experience may use the equipment.**

**Delegated persons** are those who have been properly and demonstrably instructed in their tasks and the attendant dangers.

**Qualified persons** are those who are able through training, knowledge and experience as well as knowledge of the specific details to carry out all the required tasks, identify dangers and avoid personal and other risks.

All work on electrical equipment may only be performed by qualified electricians.

## 1.7.5 Alarm signals

Alarm conditions, not danger situations, are signaled on the front of this slave device in form of a red LED “**Error**” (also see section 1.8.4.). Because the models of this series are designed to run as slave units in a master-slave system, the master unit will indicate alarms in its own available ways. Refer to the manual of series PSB 9000 3U for more information about this matter.

The LED collects all of the below listed alarm situations. If there is supervision of the slave units being used, alarms can be decoded by querying a status from the device via any of the two USB ports.

Global meaning of alarm situations as indicated by LED “Error”:

Signal <b>OT</b> (OverTemperature)	<ul style="list-style-type: none"> <li>• Overheating of the device</li> <li>• DC terminal will be switched off</li> <li>• Non-critical</li> </ul>
Signal <b>OVP</b> (OverVoltage)	<ul style="list-style-type: none"> <li>• Overvoltage shutdown of the DC terminal due to excess voltage entering the device or generated by the device itself due to a defect</li> <li>• Critical! The device and/or the load could be damaged</li> </ul>
Signal <b>OC</b> (OverCurrent)	<ul style="list-style-type: none"> <li>• Shutdown of the DC terminal due to excess of the preset limit</li> <li>• Non-critical, protects the load from excessive current consumption</li> </ul>
Signal <b>OPP</b> (OverPower)	<ul style="list-style-type: none"> <li>• Shutdown of the DC terminal due to excess of the preset limit</li> <li>• Non-critical, protects the load from excessive power consumption</li> </ul>
Signal <b>PF</b> (Power Fail)	<ul style="list-style-type: none"> <li>• DC terminal shutdown due to AC undervoltage or defect in the AC input</li> <li>• Critical on overvoltage! AC input circuit could be damaged</li> </ul>

## 1.8 Technical Data

### 1.8.1 Approved operating conditions

- Use only inside dry buildings
- Ambient temperature 0-50°C
- Operational altitude: max. 2000 m (1.242 mi) above sea level
- Max 80% relative humidity, not condensing

### 1.8.2 General technical data

Indication: 6x color LEDs

Controls: 1 pushbutton

The nominal values for the device determine the maximum adjustable ranges.



### 1.8.3 Specific technical data

15 kW	Model Slave			
	PSB 9060-360	PSB 9080-360	PSB 9200-210	PSB 9360-120
<b>AC supply</b>				
Voltage range (L-L), frequency	342..528 V AC			
Connection	3ph, PE			
Frequency range	45 - 65 Hz			
Leak current	< 3.5 mA			
Power factor	> 0.99			
Inrush current	< Maximum AC current (see 2.3.4.1)			
Efficiency of energy recovery	≤ 92%	≤ 92%	≤ 93.5%	≤ 93.5%
<b>DC terminal</b>				
Max. voltage $U_{Max}$	60 V	80 V	200 V	360 V
Max. current $I_{Max}$	360 A	360 A	210 A	120 A
Max. power $P_{Max}$	15 kW	15 kW	15 kW	15 kW
Overvoltage protection range	0...66 V	0...88 V	0...220 V	0...396 V
Overcurrent protection range	0...396 A	0...396 A	0...231 A	0...132 A
Overpower protection range	0...16.5 kW	0...16.5 kW	0...16.5 kW	0...16.5 kW
Temperature coefficient for set values $\Delta/K$	Voltage / current: 100 ppm			
Capacitance (approx.)	23970 $\mu F$	23970 $\mu F$	7560 $\mu F$	1170 $\mu F$
<b>Voltage regulation (general)</b>				
Adjustment range	0...61.2 V	0...81.6 V	0...204 V	0...367.2 V
Accuracy <sup>(1)</sup> (at 23 ± 5 °C / 73±9 °F)	< 0.1% $U_{Max}$	< 0.1% $U_{Max}$	< 0.1% $U_{Max}$	< 0.1% $U_{Max}$
Line regulation at ±10% $\Delta U_{AC}$	< 0.02% $U_{Max}$	< 0.02% $U_{Max}$	< 0.02% $U_{Max}$	< 0.02% $U_{Max}$
Remote sensing compensation	Max. 5% $U_{Max}$	Max. 5% $U_{Max}$	Max. 5% $U_{Max}$	Max. 5% $U_{Max}$
<b>Voltage regulation (power supply)</b>				
Load regulation at 0...100% $\Delta I_{OUT}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$
Rise time 10...90% $\Delta U_{OUT}$	Max. 30 ms	Max. 30 ms	Max. 30 ms	Max. 30 ms
Transient time after $\Delta I_{OUT}$	< 1.5 ms	< 1.5 ms	< 1.5 ms	< 1.5 ms
Ripple <sup>(2)</sup>	< 320 mV <sub>PP</sub> < 25 mV <sub>RMS</sub>	< 320 mV <sub>PP</sub> < 25 mV <sub>RMS</sub>	< 300 mV <sub>PP</sub> < 40 mV <sub>RMS</sub>	< 320 mV <sub>PP</sub> < 55 mV <sub>RMS</sub>
<b>Voltage regulation (el. load)</b>				
Load regulation at 0...100% $\Delta U$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$
<b>Current regulation (general)</b>				
Adjustment range	0...367.2 A	0...367.2 A	0...214.2 A	0...122.4 A
Accuracy <sup>(1)</sup> (at 23 ± 5 °C / 73±9 °F)	< 0.2% $I_{Max}$	< 0.2% $I_{Max}$	< 0.2% $I_{Max}$	< 0.2% $I_{Max}$
Line regulation at ±10% $\Delta U_{AC}$	< 0.05% $I_{Max}$	< 0.05% $I_{Max}$	< 0.05% $I_{Max}$	< 0.05% $I_{Max}$
<b>Current regulation (power supply)</b>				
Load regulation at 0...100% $\Delta U_{OUT}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$
<b>Current regulation (el. load)</b>				
Load regulation at 0...100% $\Delta U_{IN}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$
Ripple <sup>(2)</sup>	< 240 mA <sub>RMS</sub>	< 240 mA <sub>RMS</sub>	< 66 mA <sub>RMS</sub>	< 50 mA <sub>RMS</sub>

(1 Related to the nominal values, the accuracy defines the maximum deviation between an adjusted values and the true (actual) value.

Example: a 80 V model has min. 0.1% voltage accuracy, that is 80 mV. When adjusting the voltage to 5 V, the actual value is allowed to differ max. 80 mV, which means it might be between 4.92 V and 5.08 V.

(2 RMS value: LF 0...300 kHz, PP value: HF 0...20MHz

15 kW	Model Slave			
	PSB 9060-360	PSB 9080-360	PSB 9200-210	PSB 9360-120
Power regulation				
Adjustment range	0...15.3 kW	0...15.3 kW	0...15.3 kW	0...15.3 kW
Accuracy <sup>(1)</sup> (at 23 ± 5 °C / 73±9 °F)	< 1% P <sub>Max</sub>	< 1% P <sub>Max</sub>	< 1% P <sub>Max</sub>	< 1% P <sub>Max</sub>
Line regulation at ±10% ΔU <sub>AC</sub>	< 0.05% P <sub>Max</sub>	< 0.05% P <sub>Max</sub>	< 0.05% P <sub>Max</sub>	< 0.05% P <sub>Max</sub>
Load reg. at 10-90% ΔU <sub>OUT</sub> * ΔI <sub>OUT</sub>	< 0.75% P <sub>Max</sub>	< 0.75% P <sub>Max</sub>	< 0.75% P <sub>Max</sub>	< 0.75% P <sub>Max</sub>
Efficiency <sup>(2)</sup>	≈ 93%	≈ 93%	≈ 95%	≈ 94%
Internal resistance regulation				
Adjustment range	0.006...10	0.006...10 Ω	0.033...50 Ω	0.1..180 Ω
Accuracy <sup>(1)</sup>	≤ 2% of max. resistance ± 0.3% of maximum current			
Insulation	Allowed float (potential shift) on the DC terminal:			
Negative terminal to PE      Max.	±400 V DC	±400 V DC	±725 V DC	±725 V DC
Positive terminal to PE      Max.	±400 V DC	±400 V DC	±1000 V DC	±1000 V DC
AC input <-> PE	2.5 kV DC			
AC input <-> DC terminal	2.5 kV DC			
Miscellaneous				
Cooling	Temperature controlled fans, front & side inlet, rear exhaust			
Ambient temperature	0...50 °C (32...133 °F)			
Storage temperature	-20...70 °C (-4...158 °F)			
Humidity	< 80%, not condensing			
Standards	EN 61010-1, EN 50160:2011-02, EN 61000-6-2:2016-05, EN 61000-6-3:2011-09			
Overvoltage category	2			
Protection class	1			
Pollution degree	2			
Operational altitude	≤ 2000 m (1.242 mi)			
Digital interfaces				
Featured	1x USB (front side) for quick value setup 1x USB (rear side) for communication and service			
Galvanic isolation from device	Max. 1500 V DC			
Terminals				
Rear side	Share Bus, DC terminal, AC input, remote sensing, USB, master-slave bus			
Front side	USB			
Dimensions				
Enclosure (WxHxD)	19“ x 3U x 669 mm (26.3”)			
Total (WxHxD)	483 x 133 x min. 775 mm (19” x 5.2” x 30.5”)			
Weight	≈ 32 kg (70.5 lbs)	≈ 32 kg (70.5 lbs)	≈ 32 kg (70.5 lbs)	≈ 32 kg (70.5 lbs)
Article number	30090321	30090312	30090313	30090314

(1 Related to the nominal values, the accuracy defines the maximum deviation between an adjusted values and the true (actual) value  
(2 Typical value at 100% voltage and 100% power

15 kW	Model Slave			
	PSB 9500-90	PSB 9750-60	PSB 91000-40	PSB 91500-30
<b>AC supply</b>				
Voltage range (L-L), frequency	342..528 V AC			
Connection	3ph, PE			
Frequency range	45 - 65 Hz			
Leak current	< 3.5 mA			
Power factor	> 0.99			
Inrush current	< Maximum AC current (see 2.3.4.1)			
Efficiency of energy recovery	≤ 94.5%	≤ 94.5%	≤ 93.5%	≤ 94.5%
<b>DC terminal</b>				
Max. voltage $U_{Max}$	500 V	750 V	1000 V	1500 V
Max. current $I_{Max}$	90 A	60 A	40 A	30 A
Max. power $P_{Max}$	15 kW	15 kW	15 kW	15 kW
Overvoltage protection range	0...550 V	0...825 V	0...1100 V	0...1650 V
Overcurrent protection range	0...99 A	0...66 A	0...44 A	0...33 A
Overpower protection range	0...16.5 kW	0...16.5 kW	0...16.5 kW	0...16.5 kW
Temperature coefficient for set values $\Delta/K$	Voltage / current: 100 ppm			
Capacitance (approx.)	540 $\mu$ F	540 $\mu$ F	130 $\mu$ F	60 $\mu$ F
<b>Voltage regulation (general)</b>				
Adjustment range	0...510 V	0...765 V	0...1020 V	0...1530 V
Accuracy <sup>(1)</sup> (at 23 ± 5 °C / 73±9 °F)	< 0.1% $U_{Max}$	< 0.1% $U_{Max}$	< 0.1% $U_{Max}$	< 0.1% $U_{Max}$
Line regulation at ±10% $\Delta U_{AC}$	< 0.02% $U_{Max}$	< 0.02% $U_{Max}$	< 0.02% $U_{Max}$	< 0.02% $U_{Max}$
Remote sensing compensation	Max. 5% $U_{Max}$	Max. 5% $U_{Max}$	Max. 5% $U_{Max}$	Max. 5% $U_{Max}$
<b>Voltage regulation (power supply)</b>				
Load regulation at 0...100% $\Delta I_{OUT}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$
Rise time 10...90% $\Delta U_{OUT}$	Max. 30 ms	Max. 30 ms	Max. 30 ms	Max. 30 ms
Transient time after $\Delta I_{OUT}$	< 1.5 ms	< 1.5 ms	< 1.5 ms	< 1.5 ms
Ripple <sup>(2)</sup>	< 350 mV <sub>PP</sub> < 70 mV <sub>RMS</sub>	< 800 mV <sub>PP</sub> < 200 mV <sub>RMS</sub>	< 1600 mV <sub>PP</sub> < 300 mV <sub>RMS</sub>	< 2400 mV <sub>PP</sub> < 400 mV <sub>RMS</sub>
<b>Voltage regulation (el. load)</b>				
Load regulation at 0...100% $\Delta U$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$	< 0.05% $U_{Max}$
<b>Current regulation (general)</b>				
Adjustment range	0...91.8 A	0...61.2 A	0...40.8 A	0...30.6 A
Accuracy <sup>(1)</sup> (at 23 ± 5 °C / 73±9 °F)	< 0.2% $I_{Max}$	< 0.2% $I_{Max}$	< 0.2% $I_{Max}$	< 0.2% $I_{Max}$
Line regulation at ±10% $\Delta U_{AC}$	< 0.05% $I_{Max}$	< 0.05% $I_{Max}$	< 0.05% $I_{Max}$	< 0.05% $I_{Max}$
<b>Current regulation (power supply)</b>				
Load regulation at 0...100% $\Delta U_{OUT}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$
<b>Current regulation (el. load)</b>				
Load regulation at 0...100% $\Delta U_{IN}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$	< 0.15% $I_{Max}$
Ripple <sup>(2)</sup>	< 48 mA <sub>RMS</sub>	< 48 mA <sub>RMS</sub>	< 16 mA <sub>RMS</sub>	< 26 mA <sub>RMS</sub>

(1 Related to the nominal values, the accuracy defines the maximum deviation between an adjusted values and the true (actual) value.  
Example: a 80 V model has min. 0.1% voltage accuracy, that is 80 mV. When adjusting the voltage to 5 V, the actual value is allowed to differ max. 80 mV, which means it might be between 4.92 V and 5.08 V.  
(2 RMS value: LF 0...300 kHz, PP value: HF 0...20MHz

15 kW	Model Slave			
	PSB 9500-90	PSB 9750-60	PSB 91000-40	PSB 91500-30
Power regulation				
Adjustment range	0...15.3 kW	0...15.3 kW	0...15.3 kW	0...15.3 kW
Accuracy <sup>(1)</sup> (at 23 ± 5 °C / 73±9 °F)	< 1% P <sub>Max</sub>	< 1% P <sub>Max</sub>	< 1% P <sub>Max</sub>	< 1% P <sub>Max</sub>
Line regulation at ±10% ΔU <sub>AC</sub>	< 0.05% P <sub>Max</sub>	< 0.05% P <sub>Max</sub>	< 0.05% P <sub>Max</sub>	< 0.05% P <sub>Max</sub>
Load reg. at 10-90% ΔU <sub>OUT</sub> * ΔI <sub>OUT</sub>	< 0.75% P <sub>Max</sub>	< 0.75% P <sub>Max</sub>	< 0.75% P <sub>Max</sub>	< 0.75% P <sub>Max</sub>
Efficiency <sup>(2)</sup>	≈ 95%	≈ 95%	≈ 95%	≈ 95%
Internal resistance regulation				
Adjustment range	0.16...340 Ω	0.4...740 Ω	0.8...1300 Ω	2.5..3000 Ω
Accuracy <sup>(1)</sup>	≤ 2% of max. resistance ± 0.3% of maximum current			
Insulation	Allowed float (potential shift) on the DC terminal:			
Negative terminal to PE      Max.	±1500 V DC	±1500 V DC	±1500 V DC	±1500 V DC
Positive terminal to PE      Max.	±1800 V DC	±1800 V DC	±1800 V DC	±1800 V DC
AC input <-> PE	2.5 kV DC			
AC input <-> DC terminal	2.5 kV DC			
Miscellaneous				
Cooling	Temperature controlled fans, front & side inlet, rear exhaust			
Ambient temperature	0...50 °C (32...133 °F)			
Storage temperature	-20...70 °C (-4...158 °F)			
Humidity	< 80%, not condensing			
Standards	EN 61010-1, EN 50160:2011-02, EN 61000-6-2:2016-05, EN 61000-6-3:2011-09			
Overvoltage category	2			
Protection class	1			
Pollution degree	2			
Operational altitude	≤ 2000 m (1.242 mi)			
Digital interfaces				
Featured	1x USB (front side) for quick value setup 1x USB (rear side) for communication and service			
Galvanic isolation from device	Max. 1500 V DC			
Terminals				
Rear side	Share Bus, DC terminal, AC input, remote sensing, USB, master-slave bus			
Front side	USB			
Dimensions				
Enclosure (WxHxD)	19" x 3U x 669 mm (26.3")			
Total (WxHxD)	483 x 133 x min. 775 mm (19" x 5.2" x 30.5")			
Weight	≈ 32 kg (70.5 lbs)	≈ 32 kg (70.5 lbs)	≈ 32 kg (70.5 lbs)	≈ 32 kg (70.5 lbs)
Article number	30090315	30090316	30090317	30090318

(1 Related to the nominal values, the accuracy defines the maximum deviation between an adjusted values and the true (actual) value

(2 Typical value at 100% voltage and 100% power

# 1.8.4 Views




Figure 1 - Front view




Figure 2 - Rear view

- A - Power switch
- B - Control panel
- C - Rear USB port
- D - Share Bus and remote sensing connection
- E - DC terminal
- F - AC input connection
- G - Master-slave ports
- H - Plug fixture & strain relief



Figure 3 - Side view (right)




Figure 4 - Side view (left)




Figure 5 - Top view

### 1.8.5 Control elements




Figure 6 - Control Panel

#### Overview of the elements on the control panel

For a detailed description see section „1.9.4. The control panel (HMI)“.

(1)	<b>On/Off button</b> Can be used to switch the DC terminal on or off during manual operation, while LED “Remote” is off
(2)	<b>USB port</b> For quick and easy access to the most important DC terminal related values when the device isn’t in master-slave mode. This port has reduced functionality compared to the rear port.
(3)	<b>Status indicators (LED)</b> These six colour LEDs show the device status. For details refer to 1.9.4.



## 1.9 Construction and function

### 1.9.1 General description

The power supplies of the PSB 9000 3U Slave series are so-called bidirectional devices, incorporating the function of a laboratory power supply (source) and an electronic load (sink) into one unit. They allow for easy setup of applications according to the source-sink principle with a minimum of required hardware and cabling.

The sink feature is furthermore included with an energy recovery function which inverts the consumed DC energy with an efficiency of up to 95% and feeds it back into the local mains.

By default, the devices have an USB port on the rear side which serves various purposes, such as servicing (firmware updates), monitoring during master-slave operation or even remote control when the unit is being used in stand-alone operation.


The additional USB port on the front side is used for quick access to all the DC terminal related parameters and settings. The configuration via this port can be done with the included software **EPS Power Control** (on USB stick) or via any custom made control application.

The devices offer as standard the possibility for parallel connection in Share bus operation to achieve a constant current sharing, plus a genuine master-slave connection with totaling of the slave units' values. This kind of operation allows for up to 16 units to be combined to a single system with a total power of up to 240 kW.

### 1.9.2 Block diagram

The block diagram illustrates the main components inside the device and their relationships.

There are digital, microprocessor controlled components (KE, DR, HMI), which can be target of firmware updates.



## 1.9.3 Scope of delivery

- 1 x Power supply device
- 1 x Share Bus plug
- 1 x Remote sensing plug
- 1 x 1.8 m (6 ft) USB cable
- 1 x Set of DC terminal covers
- 1 x Share/Sense terminal cover (only with models from 750 V)
- 1 x USB stick with documentation and software
- 1 x AC connector plug (clamp type)
- 1 x Set for strain relief (premounted)

## 1.9.4 The control panel (HMI)

The HMI (Human Machine Interface) consists of six colored LEDs, a pushbutton and an USB-B port.

### 1.9.4.1 Status indicators (LED)

The six coloured LEDs on the front indicate various statuses of the device:

LED	Colour	Indicates what when lit?
<b>Power</b>	orange / green	Orange = device is in boot phase or internal error occurred Green = device is ready for operation
<b>Remote</b>	green	Remote control by master or any of the USB ports is active. In this situation, manual control with button On/Off is locked.
<b>Error</b>	red	At least one unacknowledged device alarm is active. The LED can signalize all alarms as listed in „3.7. Alarms and monitoring“.
<b>CC</b>	yellow	Constant current regulation (CC) is active. It means, if the LED isn't lit it indicates either CV, CP or CR mode. Also see „3.3. Operating modes“.
<b>On</b>	green	DC terminal is switched on
<b>Off</b>	red	DC terminal is switched off

### 1.9.4.2 USB port

The front USB port is easier to access than the one on the rear side and intended for quick setup of DC terminal related values and settings. Doing so is only necessary and possible in these two situations:

1. The PSB 9000 3U Slave shall run as stand-alone device which isn't controlled by a PSB 9000 3U master.
2. The PSB 9000 3U shall, due to the lack of a suitable PSB 9000 3U master device, be the master of other PSB 9000 3U Slave devices.

Both situations are only secondary, as the primary and normal function of a PSB 9000 3U Slave is to be a slave in a master-slave system where it's assigned all required settings and values from the master.

When running any of the above listed situations following applies for the USB port:



- Reduced instruction set for master-slave configuration, set values (U, I, P, R) and protections (OVP, OCP, OPP). For details about the instruction set see „3.6. Remote control“.
- Taking over remote control in order to change the configuration is only possible while the unit isn't online with the master, which either requires to temporarily deactivate master-slave on the master or to switch the master off

### 1.9.4.3 Pushbutton “On / Off”




This button can be used to switch the DC terminal on or off during manual control, i.e. the device isn't in remote control by a master or via any of the USB ports (LED “Remote” = off). Once pushed to switch the DC terminal on, the device would regulate it to the last values it has stored. Since all the DC terminal related values aren't displayed, operating that button has to be done with caution.

## 1.9.5 USB port type B (rear side)

The USB-B port on the rear side of the device is provided for communication with the device, i.e. monitoring during master-slave operation or full remote control in stand-alone operation, as well as for firmware updates. The included USB cable can be used to connect the device to a PC (USB 2.0 or 3.0). The driver is delivered with the device and installs a virtual COM port. Details for remote control can be found on the web site of the manufacturer or on the included USB stick.

The device can be addressed via this port either using the international standard ModBus protocol or by SCPI language. The device recognizes the message protocol automatically.

This USB port has no priority over either the other USB port on the front or remote control from a master unit and can, therefore, only be used for remote control alternatively to these. However, monitoring is always available.




## 1.9.6 “Share” connector

The 2 pole Phoenix socket “Share” on the rear side of the device is provided for connection to equally named sockets on compatible power supplies series to achieve a balanced load current distribution during parallel connection. The socket is also used to connect the power supply to compatible electronic loads, in order to build a two-quadrants operation setup. Following power supply and electronic load series are compatible on the so-called “Share bus”:

- PSB 9000 / PSBE 9000
- PSI 9000 2U - 24U / PSI 9000 3U Slave
- ELR 9000 / ELR 9000 HP
- EL 9000 B / EL 9000 B HP / EL 9000 B 2Q / EL 9000 B Slave
- PSE 9000
- PS 9000 1U / 2U / 3U \*

\* From hardware revision 2, see type label of those series (in case it does not show “Revision” on type label, it is revision 1)



## 1.9.7 “Sense” connector (remote sensing)

The devices of series PSB 9000 3U Slave are supposed to run as slave units in a master-slave system where the remote sensing feature is only used and connected to the master unit. For stand-alone operation outside of a master-slave setup this feature can be wired and used on the Slave mode as well.

In order to compensate for voltage drops along the DC cables to the load, the Sense input can be connected to the load. The maximum possible compensation is given in the technical specifications.


In order to ensure safety and to comply to international directives, insulation of high voltage models, i. e. such with a nominal voltage of 500 V or higher, is ensured by using only the two outer pins of the 4-pole terminal. The inner two pins, marked with NC, must remain unconnected.



## 1.9.8 Master-Slave bus

A further port is provided on the rear side of the device, comprising two RJ45 sockets, which enables multiple identical devices to be connected via a digital bus (RS485) to create a master-slave system. For a PSB 9000 3U Slave device this interface is essential, because it is configured and controlled regarding values and status via this port by a master unit.

Connection is made using standard CAT5 cables.



## 2. Installation & commissioning

### 2.1 Transport and storage

#### 2.1.1 Transport



- The handles on the front side of the device aren't for carrying!
- Because of its weight, transport by hand should be avoided where possible. If unavoidable then only the housing should be held and not on the exterior parts (handles, DC terminal, rotary knobs).
- Do not transport when switched on or connected!
- When relocating the equipment use of the original packing is recommended
- The device should always be carried and mounted horizontally
- Use suitable safety clothing, especially safety shoes, when carrying the equipment, as due to its weight a fall can have serious consequences.

#### 2.1.2 Packaging

It is recommended to keep the complete transport packaging for the lifetime of the device for relocation or return to the manufacturer for repair. Otherwise the packaging should be disposed of in an environmentally friendly way.

#### 2.1.3 Storage

In case of long term storage of the equipment it is recommended to use the original packaging or similar. Storage must be in dry rooms, if possible in sealed packaging, to avoid corrosion, especially internal, through humidity.

### 2.2 Unpacking and visual check

After every transport, with or without packaging, or before commissioning, the equipment should be visually inspected for damage and completeness using the delivery note and/or parts list (see section „1.9.3. Scope of delivery“). An obviously damaged device (e.g. loose parts inside, damage outside) must under no circumstances be put in operation.

### 2.3 Installation

#### 2.3.1 Safety procedures before installation and use




- The device may, according to model, have a considerable weight. Therefore the proposed location of the equipment (table, cabinet, shelf, 19" rack) must be able to support the weight without restriction.
- When using a 19" rack, rails suitable for the width of the housing and the weight of the device are to be used (see „1.8.3. Specific technical data“)
- Before connecting to the mains ensure that the supply voltage is as shown on the product label. Overvoltage on the AC supply can cause equipment damage.

#### 2.3.2 Preparation

##### 2.3.2.1 Planning the master-slave system

Before any further planning of installation and wiring it's recommend to decide how the master-slave system shall be configured. The smallest setup would consist of 1x PSB 9000 3U and 1x PSB 9000 3U Slave. Both, master and slave unit, must be of same rating regarding voltage, current and power. Because the PSB 9000 3U Slave models are only available with 15 kW power, they will only match the corresponding models of PSB 9000 3U series. "Match" is here related to the use of the master-slave bus, which wouldn't accept different models. It means, that paralleling a PSB 9080-120 3U with a PSI 9080-360 3U is technically possible and acceptable (due to the same voltage rating), but not supported regarding master-slave.

There are several possible combinations of standard models and Slave models:




## Combination 1:

### Multiple PSB 9000 3U (with display)

All models of the standard series can be combined to themselves in master-slave (up to 10 units on one bus)

Advantage of this combination: every unit could be master or slave; the slave show their own actual values and the entire system can also be controlled manually.

Disadvantage of this combination: higher costs compared to a system with PSB 9000 3U Slave models




## Combination 2:

### One PSB 9000 3U with one or multiple PSB 9000 3U Slave

This is the intended combination for models of PSB 9000 3U Slave series, as it can be found in series PSB 9000 15U and PSB 9000 24U, for example.

Advantage of this combination: lower costs

Disadvantages of this combination: in case the master fails, the entire system can't work. After reconfiguring any Slave unit to be master, which can be done via software and remote control, the system can continue to operate. Other: only 15 kW models of both series can be used.



## Combination 3:

### Multiple PSB 9000 3U with one or multiple PSB 9000 3U Slave

An already existing MS system with only PSB 9000 3U is going to be extended by one or multiple PSB 9000 3U Slave units.

Advantage of this combination: in case of a failing master, any other PSB 9000 3U unit can be quickly reconfigured to be master.

Disadvantages of this combination: higher costs, because even some of the slave units may have a display and control panel which they actually don't need. Other: only 15 kW models of both series can be used.



## 2.3.2.2 AC supply

AC supply connection for the PSB 9000 3U Slave series is done via the included 5 pole plug on the rear of the device. The plug requires at least conductors for three phases (L1+L2+L3) and ground (PE) with suitable cross section and length. The N conductor can be wired also, but isn't used. For a recommendation about cable cross section see „2.3.4. Connection to AC supply“.

## 2.3.2.3 DC terminal

Dimensioning of the DC wiring to the load/consumer has to reflect the following:



- The cable cross section should always be specified for at least the maximum current of the device.
- Continuous operation at the approved limit generates heat which must be removed, as well as voltage loss which depends on cable length and heating. To compensate for these the cable cross section should be increased and the cable length reduced.

## 2.3.3 Installing the device




- Select the location for the device so that the connection to the load is as short as possible.
- Leave sufficient space behind the equipment, minimum 30 cm (12"), for ventilation.

A device in a 19" housing is designed to be installed in 19" racks or cabinets, which are either lockable or at least have closable doors. This is required to achieve a sufficient protection against touching parts leading dangerous voltage.

The device can rest on rails or a shelf. When selecting those the depth of the device and its weight must be taken into account. The handles on the front are intended to help sliding it in or out of the cabinet. Slots on the front plate are provided for fixing the device (fixing screws not included).

Acceptable and unacceptable installation positions:



Standing surface

## 2.3.4 Connection to AC supply



- Connection to an AC mains supply may only be carried out by qualified personnel!
- Cable cross section must be suitable for the maximum input current of the device (see tables below)!
- Before plugging in the input plug ensure that the device is switched off by its mains switch!

The device is delivered with a 5 pole AC plug. Depending on model, the plug is connected to a 2-phase or 3-phase AC supply, according to the labeling on the plug. Required as minimum are following phases:

Rated power	Phases	Supply type
≥15 kW	L1, L2, L3, PE	Three-phase



The PE conductor is imperative and must always be wired!

### 2.3.4.1 Cross section

For the selection of a suitable cable **cross section** the rated AC current of the device and the cable length are decisive. Based on the connection of **one single unit** the table lists the maximum input current and recommended minimum cross section for each phase:

Rated power	L1		L2		L3		PE
	Ø	I <sub>max</sub>	Ø	I <sub>max</sub>	Ø	I <sub>max</sub>	Ø
15 kW	4 mm <sup>2</sup>	28 A	4 mm <sup>2</sup>	28 A	4 mm <sup>2</sup>	28 A	4 mm <sup>2</sup>

### 2.3.4.2 AC cable

The included connection plug can receive cable ends (soldered or crimped) of up to 6 mm<sup>2</sup> (AWG10). The longer the connection cable, the higher the voltage loss due to the cable resistance. Therefore the mains cables should be kept as short as possible or use bigger cross section.





Figure 7 - Example for a mains cable without N conductor (cable not included in delivery)

### 2.3.4.3 Strain relief and plug fixture

There is a standard fixture mounted to the AC input connection block on the rear. It is used to prevent the AC plug from loosening and disconnecting due to vibrations or similar. The fixture is also used as strain relief.

Being tied to the AC input block with 4x M3 acorn nuts, it is recommended to mount the fixture every time the AC plug has been removed.

It is furthermore recommended to install the strain relief by using suitable cable straps (not included), as depicted in the figure to the right.





## 2.3.5 Connection to DC loads



- In the case of a device with a high nominal current and hence a thick and heavy DC connection cable it is necessary to take account of the weight of the cable and the strain imposed on the DC connection. Especially when mounted in a 19" cabinet or similar, where the cable hangs on the DC terminal, strain reliefs should be installed.
- Connection to and operation with transformerless DC-AC inverters (for example solar inverters) is restricted, because the inverter can shift the potential of negative DC terminal (DC-) against PE (ground). Mind the max. allowed potential shift (see technical specifications)!

The DC terminal is on the rear side of the device and isn't protected by a fuse. All models in this series are designed to operate in parallel connection to at least another device of same rating, so the total current of the parallel connection can be between **60 A** (two units) and **5760 A** (16 units). From a certain current the handling of cables matching the current becomes impractical and the use of copper bars is required. The cross section of the connection cables or copper bar is determined by the maximum current, cable length and ambient temperature.







For a parallel connection of **2** units, using flexible cables of up to **5 m** (16 ft) length and an average ambient temperature of up to **50°C** we recommend following cross sections for a total current of:

<b>60 A:</b>	10 mm <sup>2</sup>	<b>120 A:</b>	35 mm <sup>2</sup>
<b>180 A:</b>	70 mm <sup>2</sup>	<b>240 A:</b>	95 mm <sup>2</sup>
<b>420 A:</b>	2x 70 mm <sup>2</sup>	<b>720 A:</b>	4x 70 mm <sup>2</sup>

**per lead** (multi-conductor, insulated, openly suspended). Single leads with, for example, 70 mm<sup>2</sup> cross section can also be replaced by 2x 25 mm<sup>2</sup> etc. For even longer cables the cross section must be increased to avoid voltage loss and overheating.

### 2.3.5.1 DC terminal types

The table below shows an overview of the various DC terminals. It is recommended that connection of load cables always utilises flexible cables with ring lugs.

Type 1: Models up to 360 V voltage rating	Type 2: Models from 500 V voltage rating
	
M8 bolt on a metal rail Recommendation: ring lug with a 8 mm hole	M6 bolt on a metal rail Recommendation: ring lug with a 6 mm hole
	
	

## 2.3.5.2 Cable lead and plastic cover


A plastic cover for contact protection is included for the DC terminal. It should always be installed. The cover for type 2 (see picture above) is fixed to the connector itself, for type 1 to the back of the device. Furthermore the cover for type 1 has break outs so that the supply cable can be laid in various directions.

When using copper bars, like they're typical for cabinets, these plastic covers aren't used. Instead it is required to make a new one which can cover the entire DC bus.




*The connection angle and the required bending radius for the DC cable must be taken into account when planning the depth of the complete device, especially when installing in a 19" cabinet or similar. For type 2 connectors only a horizontal lead can be used to allow for installation of the cover.*

Examples of the type 1 terminal:



- 90° up or down
- space saving in depth
- no bending radius



- horizontal lead
- space saving in height
- large bending radius

## 2.3.6 Grounding of the DC terminal

Grounding one of the DC terminal poles is allowed. Doing so can result in a potential shift of the grounded pole against PE.

Because of insulation, there is a max. allowed potential shift of the DC terminal poles, which also depends on the device model. Refer to „1.8.3. Specific technical data“

## 2.3.7 Connection of remote sense

Important, note: Remote sensing is only for situations when the device is operated stand-alone. Being a slave in a master-slave system, only the master receives the remote sense signal and regulates the slave accordingly via the Share bus.



Both pins „NC“ of the Sense connector must not be wired!



- Remote sensing is only effective during constant voltage operation (CV) and for other regulation modes the sense input should be disconnected, if possible, because connecting it generally increases the oscillation tendency
- The cross section of the sense cables is noncritical. Recommendation for cables up to 5 m (16 ft): use at least 0.5 mm<sup>2</sup>
- Sense cables should be twisted and laid close to the DC cables to damp oscillation. If necessary, an additional capacitor should be installed at the load/consumer to eliminate oscillation
- The + sense cables must be connected to + on the load and - sense to - at the load, otherwise the sense input of the power supply can be damaged. For an example see *Figure 8* below.




Figure 8 - Example for remote sensing wiring with a load in source mode

## 2.3.8 Connecting the “Share” bus

The “Share” bus connector on the rear side is intended to balance the current of multiple units in parallel operation, especially when using the integrated function generator of the master unit. It's recommended to wire the Share bus and keep the configuration.

For the connection of the share bus the following must be paid attention to:



- Connection is only permitted between compatible devices (see „1.9.6. “Share” connector“ for details) and between a max. of 16 units
- If a two-quadrants operation system has to be set up where multiple power supplies are connected to one electronic load unit or a group of electronic loads, all units should be connected via Share bus. One power supply unit is then configured as Share bus master, similar to true master-slave operation.
- When not using one or several units of a system configured with Share bus, because less power is required for an application, it is recommended to disconnect the unit's from the Share bus, because even when not powered they can have a negative impact on the control signal on the bus due to their impedance. Disconnection can be done by simply unplugging them from the bus or using switches.

## 2.3.9 Connecting the USB port

In order to remotely control the device via the USB ports, connect the device with a PC using the included USB cable and switch the device on.

### 2.3.9.1 Driver installation (Windows)

On the initial connection with a PC the operating system will identify the device as new hardware and will try to install a driver. The required driver is for a Communications Device Class (CDC) device and is usually integrated in current operating systems such as Windows 7 or 10. But it is strongly recommended to use and install the included driver (on USB stick) to gain maximum compatibility of the device to our softwares.

### 2.3.9.2 Driver installation (Linux, MacOS)

We can't provide drivers or installation instructions for these operating systems. Whether a suitable driver is available is best carried out by searching the Internet.

### 2.3.9.3 Alternative drivers

In case the CDC driver described above isn't available on your system, or for some reason do not function correctly, commercial suppliers can help. Search the Internet for suppliers using the keywords “cdc driver windows” or “cdc driver linux” or “cdc driver macos”.

## 2.3.10 Initial commission

For the first start-up after installation of the device, the following procedures have to be executed:

- Confirm that the connection cables to be used are of a satisfactory cross section!
- Check if the factory settings of set values, safety and monitoring functions and communication are suitable for your intended application of the device and adjust them if required, as described in the manual!
- In case of remote control via PC, read the additional documentation for interfaces and software!
- In case of remote control via the analog interface, read the section in this manual concerning analog interfaces!

## 2.3.11 Commission after a firmware update or a long period of non-use

In case of a firmware update, return of the equipment following repair or a location or configuration change, similar measures should be taken to those of initial start up. Refer to „2.3.10. *Initial commission*“.

Only after successful checking of the device as listed may it be operated as usual.

### 3. Operation and application

#### 3.1 Terms

The device is a combination of a power supply and an electronic load. It can work alternatively in one of two superior operation modes which are distinguished from each other in several parts of this document below:

- **Source / source mode:**

- the device works as a power supply, generating and providing DC voltage to an external DC load
- in this mode, the DC terminal is considered as DC output

- **Sink / sink mode:**

- the device works as an electronic load, sinking DC energy from an external DC source
- in this mode, the DC terminal is considered as DC input

#### 3.2 Personal safety



- In order to guarantee safety when using the device, it is essential that only persons operate the device who are fully acquainted and trained in the required safety measures to be taken when working with dangerous electrical voltages
- For models which can generate a voltage which is dangerous by contact, or is connected to such, the included DC terminal cover, or an equivalent, must always be used
- Whenever the load and DC terminal are being re-configured, the device should be disconnected from the mains, not only the DC terminal switched off!

#### 3.3 Operating modes

A power supply is internally controlled by different control or regulation circuits, which shall bring voltage, current and power to the adjusted values and hold them constant, if possible. These circuits follow typical laws of control systems engineering, resulting in different operating modes. Every operating mode has its own characteristics which is explained below in short form.



- *When running the device in source mode, unloaded operation isn't considered as a normal operation mode and can thus lead to false measurements, for example when calibrating the device*
- *The optimal working point of the device is between 50% and 100% voltage and current*
- *It is recommended to not run the device below 10% voltage and current, in order to make sure technical values like ripple and transient times can be met*

##### 3.3.1 Voltage regulation / Constant voltage

Voltage regulation is also called constant voltage operation (**CV**).


The voltage on the DC terminal of the device is held constant on the adjusted value, unless the current or the power according to  $P = U_{DC} \cdot I$  reaches the adjusted current or power limit. In both cases the device will automatically change to constant current or constant power operation, whatever occurs first. Then the voltage can't be held constant anymore and will sink to a value resulting from Ohm's law.

##### 3.3.1.1 Transient time after load step (source mode)


For constant voltage mode (CV), the technical date "Transient time after load step" (see 1.8.3) defines a time that is required by the internal voltage regulator of the device to settle the voltage (in source mode) after a load step. Negative load steps, i.e. high load to lower load, will cause the output voltage to overshoot for a short time until compensated by the voltage regulator.

The same occurs with a positive load step, i.e. low load to high load. There the output collapses for a moment. The amplitude of the overshoot resp. collapse depends on the device model, the currently adjusted output voltage and the capacity on the DC terminal and can thus not be stated with a specific value.

Depictions:



Example for neg. load step: the DC output voltage will rise above the adjusted value for a short time.  $t$  = transient time to settle the output voltage.



Example for pos. load step: the DC output voltage will collapse below the adjusted value for a short time.  $t$  = transient time to settle the output voltage.

### 3.3.2 Current regulation / constant current / current limiting

Current regulation is also known as current limiting or constant current mode (**CC**).

The current in the DC terminal of the device is held constant once the output current (source mode) to the load resp. the current consumed from the load (sink mode) reaches the adjusted limit. Then the device automatically switches to CC. In source mode, the current flowing from the power supply is only determined by the output voltage and the load's true resistance.

As long as the current is lower than the adjusted current limit, the device will be either in constant voltage or constant power mode. If, however, the power consumption reaches the set maximum power value, the device will switch automatically to power limiting and set voltage and current according to  $P = U \cdot I$ .


While the DC power stage is switched on and constant current mode is active, the condition "CC mode active" will be indicated by the LED "CC" on the front panel.

### 3.3.3 Power regulation / constant power / power limiting

Power regulation, also known as power limiting or constant power (**CP**), keeps the DC power constant if the current flowing to the load (source mode) resp. the current from the source (sink mode) in relation to the voltage reaches the adjusted limit according to  $P = U \cdot I$  (sink mode) resp.  $P = U^2 / R$  (source mode).

In source mode, the power limiter then regulates the output current according to  $I = \sqrt{P / R}$ , where  $R$  is the load's resistance.

Power limiting operates according to the auto-range principle such that at lower voltages higher current can flow and vice versa, always in order to maintain constant power within the range  $P_N$  (see diagram to the right).




*When using remote sensing in source mode, the device usually delivers a higher voltage on the DC output than adjusted, which results in an additional power due to line losses and may cause the device to enter power limitation without explicitly indicating "CP" (status which can be read via digital interface). In sink mode, the CP status is correctly signaled for the power consumed from the source.*



## 3.3.4 Internal resistance regulation (source mode)

Internal resistance control (abbr. CR) of power supplies is the simulation of a virtual internal resistor which is in series to the voltage source and thus also in series to the load. According to Ohm's law, this causes a voltage drop, which will result in a difference between adjusted output voltage and actual output voltage. This will work in constant current mode as well as in constant power mode, but here the output voltage will differ even more from the adjusted voltage, because then constant voltage isn't active.

The adjustable resistance range is generally defined between 0 and  $30 \cdot U_{NOM} / I_{NOM}$  of the particular model. The voltage setting in dependency of the resistance set value and the output current is done by calculation of the microcontroller and thus will be slower the other controllers inside the control circuit. Clarification:



$$U_{Act} = U_{Set} - I_{Act} \cdot R_{Set} \quad \left| \begin{matrix} P_{Set}, I_{Set} \end{matrix} \right.$$

$$P_{Ri} = (U_{Set} - U_{Act}) \cdot I_{Act}$$



*With resistance mode being activated the function generator will be unavailable and the actual power value provided by the device does not include the simulated power dissipation of  $R_i$ .*

## 3.3.5 Resistance regulation / constant resistance (sink mode)

In sink mode when the device is working as electronic load, which operating principle is based on a variable internal resistance. Constant resistance mode (CR) is almost a natural characteristic. The load attempts to set the internal resistance to the user defined value by determining the input current depending on the input voltage according to Ohm's law  $I_{IN} = U_{IN} / R_{SET}$ .

With series PSB 9000 3U (master) and PSB 9000 3U Slave, the difference between external voltage supplied and internal set value determines the true current. There are two situations:

a) *The voltage on the DC input is higher than the voltage set value*

In this situation, the above formula extends to  $I_{IN} = (U_{IN} - U_{SET}) / R_{SET}$ .

An example: the supplied voltage on the DC input is 200 V, the resistance  $R_{SET}$  is adjusted to 10  $\Omega$  and the voltage set value  $U_{SET}$  is set to 0 V. When switching the DC input on the current should go to 20 A and the actual resistance  $R_{MON}$  should show approx. as 10  $\Omega$ . When adjusting the voltage set value  $U_{SET}$  to 100 V now, the current would lower to 10 A while the actual resistance  $R_{MON}$  should remain at 10  $\Omega$ .

b) *The voltage on the DC input is equal to or lower than the voltage set value*

The device would not draw any current and enter CV mode. In a situation where the supplied input voltage is approx. equal to or oscillating around the voltage set value, the sink mode would permanently toggle between CV and CR. It is thus not advised to adjust the voltage set value to the same level as the external source.

The internal resistance is naturally limited between almost zero and maximum (resolution of current regulation too inaccurate). Because the internal resistance can't have a value of zero, the lower limit is defined to an achievable minimum. This ensures that the internal electronic load, at very low input voltages, can consume a high input current from the source, up to the adjusted current set value.

## 3.3.6 Sink-source mode switching

The switchover between sink and source mode happens automatically and only depends on the device's voltage setting and actual value on the DC terminal or the remote sense connector, if in use.

It means, that when connecting an external voltage source to the DC terminal, only the voltage set value determines the operation mode. When connecting a load which can't generate a voltage, only source mode can be run.

Rules for applications with external voltage source connected:

- If the voltage set value is higher than the actual voltage of the external source, the device will run in source mode
- If the voltage set value is lower, it will run in sink mode

To run one of both modes explicitly, i.e. without automatic switchover, it would require following:

- for "source only mode" adjust the current set value for the sink to 0
- for "sink only mode" adjust the voltage set value to 0



## 3.4 Alarm conditions



*This section only gives an overview about device alarms. What to do in case your device indicates an alarm condition is described in section „3.7. Alarms and monitoring“.*

As a basic principle, all alarm conditions are signaled optically (by LED “Error” on the front) and via the digital interface ports. For later acquisition, an alarm counter can be read via digital interface.

Some alarms require acknowledgment before the DC terminal can be switched on again, in those cases where the alarm caused the DC terminal to switch off. Acknowledgment in normal master-slave operation is done on the master unit. In other situations, like during manual operation it can be done with the pushbutton “On / Off” on the front or else by sending a specific command via digital interface.

### 3.4.1 Power Fail

Power Fail (PF) indicates an alarm condition which may have various causes:

- AC input voltage too low (mains undervoltage, mains failure)
- Defect in the input circuit (PFC) or any of the power stages is defective

As soon as a power fail occurs, the device will stop to supply or sink power and switch off the DC terminal. The condition of the DC terminal after a PF alarm can be configured. Without a display, this can only be done by sending a specific command or using the Settings app of EPS Power Control.



*Switching the device off with the power switch can't be distinguished from a supply blackout and thus the device will signalize an alarm via LED “Error” every time it's switched off. This can be ignored.*

### 3.4.2 Overtemperature

An overtemperature alarm (OT) can occur from an excess temperature inside the device and temporarily causes it to switch off the power stage(s). This can occur if the ambient temperature exceeds the maximum ambient temperature rating for the device. After cooling down, the device will automatically switch the power stage back on and the alarm doesn't require to be acknowledged.

### 3.4.3 Overvoltage protection

An overvoltage alarm (OVP) will switch off the DC power stage and can occur if:

- the device itself, when running in source mode, or an external source (in sink mode) brought a voltage to the DC terminal higher than set for the overvoltage alarm threshold (OVP, 0...103%  $U_{Nom}$ ) or the connected load somehow returns voltage higher than this threshold
- the OVP threshold has been adjusted too close above the output voltage in source mode and if the device is in CC regulation mode and then experiences a negative load step, it will make the voltage rise quickly, resulting in an voltage overshoot for a short moment which can already trigger the OVP

This function serves to warn the user acoustically or optically that the device probably has generated or experienced an excessive voltage which could damage the connected load application or the device.



- The device isn't fitted with protection from external overvoltage and could even be damaged when not powered
- The changeover from operation modes CC -> CV in source mode can cause voltage overshoots

### 3.4.4 Overcurrent protection

An overcurrent alarm (OCP) will switch off the DC power stage and can occur if:

- the current in the DC terminal reaches the adjusted OCP limit.

This function serves to protect the connected load application (source mode) or the external source (sink mode) so it this isn't overloaded and possibly damaged due to an excessive current.

## 3.4.5 Overpower protection

An overpower alarm (OPP) will switch off the DC terminal and can occur if:

- the product of the voltage and current in the DC terminal reaches the adjusted OPP limit.

This function serves to protect the connected load application (source mode) or the external source (sink mode) so that this isn't overloaded and possibly damaged due to an excessive power.

## 3.4.6 Safety OVP

This extra feature is **only built into the 60 V models** of this series. Similar to the regular overvoltage protection (OVP, see 3.4.3), the Safety OVP is supposed to protect the application or people according to SELV. The alarm shall prevent the device from providing an output voltage higher than 60 V. However, the alarm could also be triggered by an external source providing an excess voltage to the DC input of the device.

A safety OVP alarm can occur if

- the voltage on the DC terminal of the device exceeds the rigid threshold 60.6 V.

If the voltage on the DC terminal exceeds that level for any reason, the DC terminal will be switched off and the alarm will be indicated by LED "Error" on the control panel. This alarm can't be acknowledged the usual way. It requires to power-cycle the unit.



*During normal operation of the power supply, this alarm should not trigger. There are, however, situations which can trigger the alarm, like when working with voltages close to the threshold of 60.6 V or higher than expected voltage overshoots when leaving CC mode while  $I = 0$  A.*



When remote sensing used, i. e. the rear input "Sense" is connected, the true output voltage (in source mode) is usually higher, so the Safety OVP could already trigger at voltage settings lower than 60 V.

## 3.5 Manual operation

Manual operation is a secondary functionality for this type of device. It is intended to run under constant remote control by a master unit. Thus the number of available functions in manual control is reduced, compared to a standard PSB 9000 3U device.

### 3.5.1 Powering the device

The device should, as far as possible, always be switched on using the rotary switch on the front of the device. Alternatively this can take place using an external cutout (contactor, circuit breaker) of suitable current capacity.

In a master-slave system it is normal that not all units are powered at the same time or some units not at all. In order for the master to initialize all slaves correctly it will wait some time after start. In case not all slaves have been initialized the procedure to find and enumerate the slave can be repeated, either directly on the screen of the master, here a device from PSB 9000 3U series, or in the MENU. Alternatively, this can also be done via remote control.

After switching on, the device indicates the boot phase with LED "Power" on the front being **orange**. Once it has finished booting and is ready for operation, LED "Power" changes to **green**.

There is a configurable option which determines the condition of the DC terminal after power-up. Factory setting here is "OFF". Changing it to "Restore" will cause the device to restore the last DC terminal condition, either on or off.

In master-slave operation and when the device is being slave, which is the default mode of operation for models of this series, all values and conditions are stored and restored by the master, overwriting the slaves' settings.

### 3.5.2 Switching the device off

On switch-off, the last DC terminal condition and the most recent set values are saved. Furthermore, a PF alarm (power failure) will be signaled via LED "Error", but can be ignored.

The DC terminal is immediately switched off and after a short while fans will shut down and after another few seconds the device will be completely powered off.

### 3.5.3 Switching the DC terminal on or off

As long as the Slave unit isn't in remote control by a master unit or by a software via USB interface, the DC terminal can be manually switched on or off with the pushbutton "On / Off". This is for situations where the Slave device needs to be operated stand-alone or as substitute of a failed or missing master. The same situation also allows for access to all DC terminal related parameters via the front USB port. The button can also be used to acknowledge device alarms signaled by LED "Error".

Configuration of parameters via one of the USB ports is considered as remote control and is thus described in 3.6.



*From HMI panel firmware version 2.02 (can be read by using EPS Power Control when being connected via the front USB) it's possible to use this button to reconfigure the device as slave by pushing it for at least 10 seconds while the DC terminal is switched off. This can help in situations when the master wouldn't detect the slave anymore and no particular other reason is obvious.*

## 3.6 Remote control

### 3.6.1 General

Remote control is essential when operating devices of this series, for example during master-slave. It is furthermore possible to take over remote via one of the built-in USB ports. Important here is that only one of the digital interfaces or a master unit can be in control. It means that if, for example, an attempt were to be made to switch to remote control via the digital interface whilst master-slave mode is running the device would report an error via the digital interface. In the opposite direction, the master unit could not initialize a Slave unit being in USB remote control. In both cases, however, status **monitoring** and reading of values via any of the USB ports is always possible.

### 3.6.2 Remote control via the rear USB

The rear USB port offers the same set of commands as with a "normal" PSB 9000 3U device, but only while the Slave device isn't in control by a master device or currently not in status "Slave". Then the same programming documentation "Programming SCPI & ModBus" is valid for the user, as well as the ModBus register list "Modbus\_Register\_PSB9000\_KEx.xx+\_EN.pdf".

Control via software EPS Power Control is also possible via this port and unrestricted.

### 3.6.3 Remote control via the front USB

The main purpose of the front USB port is quick access to the most important DC terminal related parameters, such as set values and protections. Reading values and status is always possible, setting them only while the Slave device isn't in control by a master device.

Outside of master-slave, the device could be controlled remotely with software EPS **Power Control**, but also from custom applications. In order to do so, a programming documentation is delivered with the device on USB stick.

The number of available commands is restricted on this USB port, but it supports both, SCPI and ModBus RTU communication protocols. As part of the programming documentation, there is an **extra ModBus register list** (Modbus\_Register\_PSB9000\_Slave\_Front\_HMIx.xx+\_EN.pdf) for the front USB port.

In the programming guide there is a section for all SCPI commands, as available with the rear USB port. Here is an overview what commands are available with the front port. Details about the commands can be found in the "Programming SCPI & ModBus" document, also called **programming guide**.

*IDN?	SINK:RESistance?
*CLS	SINK:RESistance:LIMit:HIGH?
*RST	[SOURce:]CURRent
*ESE	[SOURce:]CURRent?
*ESE?	[SOURce:]CURRent:LIMit:HIGH?
*ESR	[SOURce:]CURRent:LIMit:LOW?
*STB?	[SOURce:]CURRent:PROTection[:LEVel]
MEASure:[SCALar:]CURRent[:DC]?	[SOURce:]CURRent:PROTection[:LEVel]?
MEASure:[SCALar:]POWER[:DC]?	[SOURce:]POWER
MEASure:[SCALar:]VOLTage[:DC]?	[SOURce:]POWER?
OUTPut[:STATe]	[SOURce:]POWER:LIMit:HIGH?
OUTPut[:STATe]?	[SOURce:]POWER:PROTection[:LEVel]
SINK:CURRent	[SOURce:]POWER:PROTection[:LEVel]?
SINK:CURRent?	[SOURce:]RESistance
SINK:CURRent:LIMit:HIGH?	[SOURce:]RESistance?
SINK:CURRent:LIMit:LOW?	[SOURce:]RESistance:LIMit:HIGH?
SINK:CURRent:PROTection[:LEVel]	[SOURce:]VOLTage
SINK:CURRent:PROTection[:LEVel]?	[SOURce:]VOLTage?
SINK:POWER	[SOURce:]VOLTage:LIMit:HIGH?
SINK:POWER?	[SOURce:]VOLTage:LIMit:LOW?
SINK:POWER:LIMit:HIGH?	[SOURce:]VOLTage:PROTection[:LEVel]
SINK:POWER:PROTection[:LEVel]	[SOURce:]VOLTage:PROTection[:LEVel]?
SINK:POWER:PROTection[:LEVel]?	STATus:OPERation?
SINK:RESistance	STATus:QUESTionable?

SYSTem:ALARm:ACTIon:PFaiL	SYSTem:CONFig:UVD
SYSTem:ALARm:ACTIon:PFaiL?	SYSTem:CONFig:UVD?
SYSTem:ALARm:COUNT:OCURrent?	SYSTem:CONFig:UVD:ACTIon
SYSTem:ALARm:COUNT:OPOWer?	SYSTem:CONFig:UVD:ACTIon?
SYSTem:ALARm:COUNT:OTEMperature?	SYSTem:DEVice:CLAss?
SYSTem:ALARm:COUNT:OVOLTage?	SYSTem:ERRor:ALL?
SYSTem:ALARm:COUNT:PFaiL?	SYSTem:ERRor:NEXT?
SYSTem:COMMunicate:TIMEout?	SYSTem:ERRor?
SYSTem:CONFig:MODE	SYSTem:LOCK
SYSTem:CONFig:MODE?	SYSTem:LOCK?
SYSTem:CONFig:OCD	SYSTem:LOCK:OWNer?
SYSTem:CONFig:OCD?	SYSTem:NOMinal:CURRent?
SYSTem:CONFig:OCD:ACTIon	SYSTem:NOMinal:POWer?
SYSTem:CONFig:OCD:ACTIon?	SYSTem:NOMinal:RESistance:MAXimum?
SYSTem:CONFig:OPD	SYSTem:NOMinal:RESistance:MINimum?
SYSTem:CONFig:OPD?	SYSTem:NOMinal:VOLTage?
SYSTem:CONFig:OPD:ACTIon	SYSTem:SINK:ALARm:COUNT:OCURrent?
SYSTem:CONFig:OPD:ACTIon?	SYSTem:SINK:ALARm:COUNT:OPOWer?
SYSTem:CONFig:OUTPut:RESTore	SYSTem:SINK:CONFig:OCD
SYSTem:CONFig:OUTPut:RESTore?	SYSTem:SINK:CONFig:OCD?
SYSTem:CONFig:OVD	SYSTem:SINK:CONFig:OCD:ACTIon
SYSTem:CONFig:OVD?	SYSTem:SINK:CONFig:OCD:ACTIon?
SYSTem:CONFig:OVD:ACTIon	SYSTem:SINK:CONFig:OPD
SYSTem:CONFig:OVD:ACTIon?	SYSTem:SINK:CONFig:OPD?
SYSTem:CONFig:UCD	SYSTem:SINK:CONFig:OPD:ACTIon
SYSTem:CONFig:UCD?	SYSTem:SINK:CONFig:OPD:ACTIon?
SYSTem:CONFig:UCD:ACTIon	SYSTem:SINK:CONFig:UCD
SYSTem:CONFig:UCD:ACTIon?	SYSTem:SINK:CONFig:UCD?
SYSTem:CONFig:USER:TEXT	SYSTem:SINK:CONFig:UCD:ACTIon
SYSTem:CONFig:USER:TEXT?	SYSTem:SINK:CONFig:UCD:ACTIon?

### 3.6.4 Programming

Programming details about the communication protocols etc. are to be found in the documentation "Programming Guide ModBus & SCPI" which is supplied on the included USB stick or which is available as download from the manufacturer's website.

### 3.7 Alarms and monitoring

#### 3.7.1 Definition of terms

The device signalizes alarms (see „3.4. Alarm conditions“) such as overvoltage (OV) or overheating (OT) via the front LED “Error” and as readable status via digital interface. When running the device as Slave as part of a master-slave system, the alarm is also reported to the master and if the master is with display, the alarm is indicated there as well. Basically, device alarms will switch off the DC terminal, primarily in order to protect the connected load or external source, and only secondarily to protect the device itself.

Monitoring or supervision is also available in form of user-definable events. Configuration of alarm thresholds and events, as well as reading status can only be done via the USB ports.

#### 3.7.2 Device alarm and event handling

A device alarm incident will usually lead to DC terminal switch-off and the front LED “Error” is lit to make the user aware. Some alarms must be acknowledged. While the Slave device is in control of a master device, all alarms are acknowledged on the master unit. Refer to the user manual of the master. After acknowledging the alarm on the master, the LED “Error” on the alarm causing slave unit should be off.

For all other situations, the front button “On / Off” or a specific command sent via digital interface in remote control is used to acknowledge alarms.

##### ► How to acknowledge an alarm (during manual control)

1. In case the DC terminal is switched off and the LED “Error” is lit, use button “On / Off”.
2. The LED should go off and with another push on “On / Off”, the DC terminal could be switched on again. If the LED remains lit, the alarm cause could still be present.

Some device alarms, specifically their thresholds, are configurable via EPS **Power Control** software or custom tools:

Short	Long	Description	Range
<b>OVP</b>	<b>OverVoltage Protection</b>	Triggers an alarm if the voltage on the DC terminal reaches the defined threshold. The DC terminal will be switched off.	0 V...1.1*U <sub>Nom</sub>
<b>OCP</b>	<b>OverCurrent Protection</b>	Triggers an alarm if the current in the DC terminal reaches the defined threshold. The DC terminal will be switched off.	0 A...1.1*I <sub>Nom</sub>
<b>OPP</b>	<b>OverPower Protection</b>	Triggers an alarm if the output or input power reaches the defined threshold. The DC terminal will be switched off.	0 W...1.1*P <sub>Nom</sub>

These device alarms can't be configured and are based on hardware:

Short	Long	Description
<b>PF</b>	<b>Power Fail</b>	AC supply over- or undervoltage. Triggers an alarm if the AC supply is out of specification or when the device is cut from supply, for example when switching it off with the power switch. The DC terminal will be switched off.
<b>OT</b>	<b>OverTemperature</b>	Triggers an alarm if the internal temperature reaches a certain limit. The DC terminal will be switched off.
<b>MSP</b>	<b>Master-Slave Protection</b>	Triggers an alarm if the master unit loses contact to any slave unit or vice versa. The DC terminal will be switched off. The alarm can be cleared by reinitializing the MS system.
<b>Safety OVP</b>	<b>Safety OverVoltage Protection</b>	Only featured in the 60 V model: Triggers a special OVP alarm if the voltage on the DC terminal exceeds the rigid threshold of 101% rated voltage. The DC terminal will be switched off. For details refer to section 3.4.6



### 3.7.2.1 User defined events

The monitoring functions of the device can be configured for user defined events. By default, events are deactivated (action = NONE). Contrary to device alarms, the events only work while the DC terminal is switched on. It means, for instance, that you can't detect undervoltage (UVD) anymore after switching the DC terminal off and the voltage is still sinking.

The following events can be configured independently and can in each case trigger the actions NONE, SIGNAL, WARNING or ALARM.

Action	Impact
NONE	User defined event is disabled.
SIGNAL/WARNING	On reaching the condition which triggers the event with action <b>SIGNAL</b> or <b>WARNING</b> a bit in the status register of the device will be set. That register can be read via USB. With this series, actions <b>SIGNAL</b> and <b>WARNING</b> are equal.
ALARM	On reaching the condition which triggers the event with action <b>ALARM</b> a bit in the status register of the device will be set and the DC terminal will be switched off. Both conditions can be read via USB from the status register.

Event	Meaning	Description	Range
UVD	UnderVoltage Detection	Triggers an event if the voltage falls below the defined threshold.	0 V...U <sub>Nom</sub>
OVD	OverVoltage Detection	Triggers an event if the voltage exceeds the defined threshold.	0 V...U <sub>Nom</sub>
UCD	UnderCurrent Detection	Triggers an event if the current falls below the defined threshold.	0 A...I <sub>Nom</sub>
OCD	OverCurrent Detection	Triggers an event if the current exceeds the defined threshold.	0 A...I <sub>Nom</sub>
OPD	OverPower Detection	Triggers an event if the power exceeds the defined threshold.	0 W...P <sub>Nom</sub>

As soon as an event is set up with an action other than "NONE" while the DC terminal is still switched on, it can immediately occur and switch the DC terminal off. It is thus recommended to configure events only while the DC terminal is switched off.



## 4. Service and maintenance

### 4.1 Maintenance / cleaning

The device needs no maintenance. Cleaning may be needed for the internal fans, the frequency of cleanse is depending on the ambient conditions. The fans serve to cool the components which are heated by the inherent power loss. Heavily dirt filled fans can lead to insufficient airflow and therefore the DC terminal would switch off too early due to overheating or possibly lead to defects.

Cleaning the internal fans can be performed with a vacuum cleaner or similar. For this the device needs to be opened.

### 4.2 Fault finding / diagnosis / repair

If the equipment suddenly performs in an unexpected way, which indicates a fault, or it has an obvious defect, this can't and must not be repaired by the user. Contact the supplier in case of suspicion and elicit the steps to be taken.

It will then usually be necessary to return the device to the supplier (with or without guarantee). If a return for checking or repair is to be carried out, ensure that:

- the supplier has been contacted and it is clarified how and where the equipment should be sent.
- the device is in fully assembled state and in suitable transport packaging, ideally the original packaging.
- a fault description in as much detail as possible is attached.
- if shipping destination is abroad, the necessary customs papers are attached.

#### 4.2.1 Firmware updates



Firmware updates should only be installed when they can eliminate existing bugs in the firmware in the device or contain new features.

The firmware of the control panel (HMI), of the communication unit (KE) and the digital controller (DR), if necessary, is updated via the rear side USB port. For this the software EPS Power Control is needed which is included with the device or available as download from our website together with the firmware update, or upon request.

However, be advised not to install updates promptly. Every update includes the risk of an inoperable device or system. We recommend to install updates only if...

- an imminent problem with your device can directly be solved, especially if we suggested to install an update during a support case
- a new feature has been added which you definitely want to use. In this case, the full responsibility is transferred to you.

Following also applies in connection with firmware updates:

- Simple changes in firmwares can have crucial effects on the application the devices are used in. We thus recommend to study the list of changes in the firmware history very thoroughly.
- Newly implemented features may require an updated documentation (user manual and/or programming guide, as well as LabView VIs), which is often delivered only later, sometimes significantly later

## **5. Contact and support**

### **5.1 General**

Repairs, if not otherwise arranged between supplier and customer, will be carried out by the manufacturer. For this the device must generally be returned to the manufacturer. No RMA number is needed. It is sufficient to package the equipment adequately and send it, together with a detailed description of the fault and, if still under guarantee, a copy of the invoice, to the following address.

### **5.2 Contact options**

Questions or problems with operation of the device, use of optional components, with the documentation or software, can be addressed to technical support either by telephone or e-Mail.

Address	e-Mail	Telephone
EPS Stromversorgung GmbH Alter Postweg 101 86159 Augsburg Germany	All issues: info@eps-germany.de	Switchboard: +49 821 / 570451-0

